

Cleaning Multiple Kennels (Without Drains) Using ANIVAC System

Preparation:

- Have all necessary supplies & equipment present to minimize movement in & out of the designated work area
- Use only manufactures authorized tools and accessories for ANIVAC system
- Confirm protocols, dilutions & contact times for cleaner/disinfectant being used
- Prep portable units with de-foamer if necessary (not required for central system)
- Use new (clean) dedicated cleaning cloth for each kennel
- Wear Personal Protection Equipment (PPE) as needed

Daily Cleaning Protocol (for same occupants):

1. Remove dog(s) from kennel
2. Macro clean:
 - For items that will be kept in the kennel that should not get wet gently remove any debris into the trashcan and place on top of none soiled surface within the kennel perimeter (i.e. on top of bed or kennel)
 - Clean &/or replace any soiled items if necessary
 - Wash or spray gloved hands with disinfect solution
 - REPEAT for each kennel
 - Scoop feces, hair and debris and dispose of in lined trashcan
 - REPEAT for each kennel
 - After final kennel thoroughly clean scoop, rinse or spray with disinfectant solution & hang up to dry
3. Using designated ANIVAC Floor Tool Kit, clean floors by starting in farthest left corner and work backwards (left-right) in an 'N' pattern, cleaning the entire floor (paying close attention to all surface areas previously in contact w/ the pooper scoop) and leaving enough cleaning/disinfecting solution behind for surfaces to stay wet for the required contact time
4. Tap vacuum head on kennel floor to dislodge any debris or organic material from the vacuum head & vacuum up



5. REPEAT for each kennel
6. Thoroughly clean & disinfect vacuum head including squeegee, brush & wheels after cleaning the last kennel
7. Verify required contact time has elapsed
8. Allow to air dry or repeat step 3 with the vacuum only using same 'N' pattern to remove any remaining solution, debris and to expedite drying process
NOTE: spray entire vacuum head, especially the underside (squeegee, brush and wheels), with disinfectant between kennels
9. REPEAT for each kennel
10. After cleaning final kennel:
 - Complete recommended daily maintenance of ANIVAC unit (see ***ANIVAC Basic Care instructions***)
 - Store on designated area
11. Rinse out dishes and provide fresh water & food
12. Place additional items (bedding, toys, etc.) back into kennel
13. Wash or spray gloved hands with disinfect solution
14. REPEAT for each kennel
15. Remove gloves & wash hands thoroughly after final kennel
16. Allow kennel to dry completely before reintroducing dog(s)

Deep Cleaning Protocol (for new occupants):

1. Remove dog(s) from kennel
2. Macro Clean:
 - Remove all bedding, toys, bowls, etc. & place used items in designated enclosed receptacles (i.e. 5-gal buckets-dishes & toys; lined trash can- organic material & debris; solid sided container w/ lid-laundry)
 - Prop up items such as sleeping platforms to expose underside for cleaning/disinfecting
 - REPEAT for each kennel
 - Scoop feces, hair and debris and dispose of in lined trashcan
 - REPEAT for each kennel
 - After final kennel thoroughly clean scoop, rinse or spray with disinfectant solution & hang up to dry
3. Using designated ANIVAC Floor Tool Kit, **without the vacuum suction being turned on**, work top-bottom and left-right:
 - Spray all surfaces including cage door, walls, sleeping platform, floor, cage card holders, etc. with just enough solution to coat evenly
 - Scrub as needed
4. Turn vacuum suction "ON" and clean floors by starting in farthest left corner and work backwards (left-right) in an 'N' pattern, cleaning the entire floor (paying close attention to all surface areas previously in contact w/ the pooper scoop) and leaving enough cleaning/disinfecting solution behind for surfaces to stay wet for the required contact time
NOTE: Utilize detail brush head(s) along edges & corners, cage doors, etc. as needed
5. Tap vacuum head on kennel floor to dislodge any debris or organic material from the vacuum head & vacuum it up
6. Spray and wipe vacuum head, especially the underside (squeegee, brush and wheels), with dedicated disinfectant-soaked cleaning cloth between kennels
7. REPEAT for each kennel
8. Thoroughly clean & disinfect vacuum head after cleaning the final kennel
9. After required contact time has elapsed:



- Wipe down all surfaces (except the floor) with dedicated cleaning cloth paying close attention to hard to reach places like the top & bottom of the kennel door

TIP- start with glass, glazed tile or stainless steel surfaces to avoid streaking

- Repeat step 4 with the **vacuum only** using same 'N' pattern to remove any remaining solution, debris and to expedite drying process

10. After vacuuming final kennel:

- Complete recommended daily maintenance of ANIVAC unit (see ***ANIVAC Basic Care Instructions***)
- Store on designated area
- Remove gloves & wash hands thoroughly

11. Allow kennels to dry completely